

How to measure for your overlay doors and drawer fronts

DO NOT ORDER BY OPENING SIZE DIMENSIONS

- 1) **Choose** your hinges first:

This will determine what size overlay is needed.

- 2) **Measure** opening size to the nearest 1/16.

Notate Height and Width.

- 3) **Add** overlay amount to each opening size according to the hardware you selected.

If you have two doors in the same opening with no stile separating the doors (Buddv doors) you need to divide by 2. This will give you the size of each door.

REMEMBER THAT WE BUILD ACCORDING TO YOUR SPECIFICATIONS.